



Thank you for purchasing this Coffee Table Vista. Please read the instructions carefully before use to ensure safe and satisfactory operation of this product.



Pre-assembly preparation

Please ensure instructions are read in full before attempting to assemble this product

Necessary tools and persons required



Please check the pack contents before attempting to assemble this product. A full checklist of components is given in this leaflet. If any components are missing, please contact the retailer from whom you bought this product.

This product is **HEAVY**, it should be assembled as near as possible to the point of use. **TAKE CARE WHEN LIFTING** to avoid personal injury and (or) damage to the product.









This product takes approximately **15 MINUTES** to assemble with **2 PEOPLE**.

The fittings pack contains **SMALL ITEMS** which should be **KEPT AWAY FROM YOUNG CHILDREN**.

Read this leaflet in full before commencing assembly.

PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE


Fittings and parts checklist

A	Legs table x2		E	Bolt M6*30 x4	
B	Tie bar x2		F	Flat washer x8	
C	Table top x1		G	Spring washer x8	
D	Bolt M6*20 x4		H	Allen key x1	

Step by step assembly instructions


Step One

Connect legs (A) & tie bar (B), tighten bolt (D), flat washer (F), spring washer (G) with allen key (H).



Step Two


Connect the part from step one & table top (C), tighten bolt (E), flat washer (F), spring washer (G) with allen key (H).



Step by step assembly instructions

Step Three

Put the table upright and make sure all legs are level, then firmly tighten bolts with allen key (H).



Care and Maintenance

How to care for your outdoor furniture

- Wash your outdoor furniture annually, scrub with soapy water followed by a thorough rinse.
- Periodically check all fixings to ensure none have come loose and re-tighten where necessary.
- Do not drag any objects across the surface, as this can cause permanent damage.
- We recommend that all garden furniture is covered when not in use and stored for winter. Ensure your furniture is clean and completely dry before being covered. The cover must be breathable to prevent mildew and/or mould developing. If storing away, ensure the space is not heated but dry with good airflow.

Safety instructions

- Please take care when handling or moving the furniture, careless handling may cause damage or injury.
- Furniture can be dangerous if incorrectly installed. Assembly should be carried out by a competent person. No liability will be accepted for damage or injury caused by incorrectly installed or assembled furniture.
- It is recommended that before moving heavy objects to a new location they are completely dis-assembled to avoid personal injury or damage to the furniture. Please be careful to retain all fittings when doing this.